

L-20R Firmware Update Guide

Copyright(C) 2020 ZOOM Corporation. All Rights Reserved.

●Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.

The illustrations in these instructions might differ from actual screens.

Updating the firmware

The **L-20R** firmware can be updated to the latest versions.

1. Copy the firmware update file to the root directory on an SD card.

NOTE

Files for the latest firmware updates can be downloaded from the ZOOM website (www.zoom.co.jp).

2. Insert the SD card into the **L-20R**.

3. While pressing , set  to ON.

4. Press .



NOTE

During the firmware update, do not turn the power off or remove the SD card. Doing so could cause the **L-20R** to become unstartable. In the unlikely event that a firmware update should fail while in progress, conduct the procedures from the beginning to update the firmware again.

5. After the firmware update completes, turn the  off.

