



MS-60B Firmware Update Guide (Mac)

Copyright(C) 2019 ZOOM Corporation. All Rights Reserved.

● Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.

• Macintosh®, Mac®, Mac OS®, OS X® and macOS® are trademarks or registered trademarks of Apple Inc.
Note: Other Product names, registered trademarks and company names in this document are the property of their respective companies.
Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The illustrations in these instructions might differ from actual screens.

Contents

1. Introduction.....	2
Precautions	2
2. Updating the firmware	3

1. Introduction


Thank you very much for downloading the firmware update application for the MS-60B.


This document explains how to update the firmware for the MS-60B.

Precautions

- 1) **Log in to your Mac computer using an account with administrator privileges.**
- 2) **Before starting this application, shut down all other applications that are running.**
In addition, if any MIDI or audio devices are connected by USB cable to the computer you are using, disconnect them all.

2. Updating the firmware


- 2.1 While pressing both  the up and down cursor keys, use a USB cable to connect the USB connector to the computer.



The FIRMWARE UPDATE screen appears.




- 2.2 Double-click the firmware update application icon to launch.



- 2.3 With a MS-60B, click the “MIDI IN” and “MIDI OUT” fields to open lists of MIDI devices and select “ZOOM MS Series” for both.
If nothing is shown in the fields, click [Rescan Device] button.


2.4 Click the [Execute] button to start the firmware update. The progress of the firmware update appears as a bar like this.



Do not disconnect the USB cable while the firmware is being updated.

In the unlikely event that a firmware update should fail, follow the procedures from step 2.1 to update the firmware again.

2.5 When the firmware update completes, it will appear as follows.



Click the [Exit] button to close the firmware update application. Then, turn the MS-60B power off.

This completes the firmware update.