

MS-70CDR v2.00 Firmware Update Guide

For Mac

Copyright(C) 2017 ZOOM Corporation. All Rights Reserved.

● Zoom Corporation will bear no responsibility for losses or claims from third parties that result from the use of this software. Moreover, without our permission, distributing, selling, leasing, renting, altering or reverse engineering of this software is prohibited. Furthermore, the specifications of this software and the contents of this document could be changed without notice in the future.

Macintosh®, Mac®, Mac OS®, OS X® and macOS® are trademarks or registered trademarks of Apple Inc.

Note: Other Product names, registered trademarks and company names in this document are the property of their respective companies.

Note: All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The explanatory illustrations in this manual might differ in appearance from the actual screens on the unit.

1. Supported operating systems

Mac® OS X® 10.10.2 (or later)

Important preparations

1) Log in to your Mac using an account with administrator privileges.

2) Before launching this application, quit all other running applications.

2. Introduction

Thank you for downloading the “ZOOM MS-70CDR v2.00 Updater” application.

This document explains how to update the MS-70CDR firmware.

3. Checking the MS-70CDR firmware versions

Following the procedures on page 22 of the MS-70CDR operation manual, check the firmware versions of your MS-70CDR. If the SYSTEM version is v2.00 or higher, you do not need to use this application to update the firmware. If the system version is lower than v2.00, follow the procedures below to update the firmware.

4. Updating the firmware


Before updating the firmware, if any MIDI or audio devices are connected by USB cable to the Mac you are using, disconnect them all. In addition, if any applications are running, quit them all.

- 4.1. When the MS-70CDR power is OFF, while pressing and holding both its up and down keys, connect it by USB cable to a USB port on the Mac.


This operation puts the MS-70CDR into a state ready to receive a firmware update, and its display shows a firmware update standby screen.

- 4.2. Double-click the “ZOOM MS-70CDR v2.00 Updater.app” icon for the firmware updating application to launch it.

After launching, a window that looks like this appears.




- 4.3. Confirm that “ZOOM MS Series” appears in both the “MIDI IN” and “MIDI OUT” fields. If it does not, click the field to open a list of MIDI devices and select “ZOOM MS Series.”
- 4.4. Click the **Execute** button to start the firmware update. The progress of the firmware update appears as a bar like this.



Do not disconnect the USB cable while the firmware is being updated.

4.5. When the firmware update completes, a message like this appears.



click **Exit** to quit the firmware updater application.

When “Complete” appears on the MS-70CDR display, disconnect the USB cable and turn its power off.

Turn the MS-70CDR power ON again and confirm that the BOOT version is now v1.10 and the SYSTEM version is now v2.00.

This completes the firmware update.