

Guitar Effects & USB Audio I/F Pedal G1u

System Software Version History

The System Software Version is shown as below.

1. Turn the power on while holding down the [BANK UP·TAP] key and the [▲] foot switch.

The higher two digits of the current version are shown on the display.

2. Press the [▲] foot switch.

The lower two digits of the current version are shown on the display.

3. Pressing either [▼]/[▲] foot switches.

The G1u re-starts.

You can download the latest system software for free at the web site below. Installation procedures, possible problems and Frequently Asked Questions are also included.

<http://www.zoom.co.jp/>

Version 1.20

- **Released as following bug fix on April 2010**

1. Fixed the problem that the display is disappeared in adjusting the reference pitch of tuner.
2. Fixed the problem that the pre-selected patch number is replaced in pre-select store mode.

Version 1.10

- **Released as following bug fix on November 2009**

1. Fixed the problem that patch will be off by one when G1u is rebooted from BYPASS mode.
2. Fixed the error of delay-time between the value shown at edit and the actual value.

Version 1.00

- **Released as mass production on May 2009**